



Hybrid Security Control Panel

User Manual

Legal Information

User Manual

©2019 Hangzhou Hikvision Digital Technology Co., Ltd.

About this Manual

This Manual is subject to domestic and international copyright protection. Hangzhou Hikvision Digital Technology Co., Ltd. ("Hikvision") reserves all rights to this manual. This manual cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of Hikvision.

Please use this user manual under the guidance of professionals.

Trademarks

HIKVISION and other Hikvision marks are the property of Hikvision and are registered trademarks or the subject of applications for the same by Hikvision and/or its affiliates. Other trademarks mentioned in this manual are the properties of their respective owners. No right of license is given to use such trademarks without express permission.

Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, REGARDING THIS MANUAL. HIKVISION DOES NOT WARRANT, GUARANTEE, OR MAKE ANY REPRESENTATIONS REGARDING THE USE OF THE MANUAL, OR THE CORRECTNESS, ACCURACY, OR RELIABILITY OF INFORMATION CONTAINED HEREIN. YOUR USE OF THIS MANUAL AND ANY RELIANCE ON THIS MANUAL SHALL BE WHOLLY AT YOUR OWN RISK AND RESPONSIBILITY.

REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.

SURVEILLANCE LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS THE APPLICABLE LAW. HIKVISION SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THIS MANUAL AND THE APPLICABLE LAW, THE LATER PREVAILS.

Symbol Conventions

The symbols that may be found in this document are defined as follows.

Symbol	Description
 Danger	Indicates a hazardous situation which, if not avoided, will or could result in death or serious injury.
 Caution	Indicates a potentially hazardous situation which, if not avoided, could result in equipment damage, data loss, performance degradation, or unexpected results.
 Note	Provides additional information to emphasize or supplement important points of the main text.

Contents

Chapter 1 System Description	1
Chapter 2 Specifications	2
Chapter 3 Activation	5
3.1 Activate Device via Web Browser	5
3.2 Activate Device via iVMS-4200	5
3.3 Activate via SADP	6
Chapter 4 Configuration	8
4.1 Use the Client Software	8
4.2 Use the Web Client	8
4.2.1 Communication Settings	9
4.2.2 Device Management	22
4.2.3 Partition Settings	29
4.2.4 Video Management	33
4.2.5 Permission Management	36
4.2.6 Maintenance	38
4.2.7 System Settings	40
4.2.8 Check Status	46
4.3 Use Mobile Client	46
4.3.1 Download and Login the Mobile Client	46
4.3.2 Add Control Panel to the Mobile Client	47
4.3.3 Add Peripheral to the Control Panel	48
4.3.4 Add a Camera to the Zone	49
4.3.5 Set Zone	50
4.3.6 Arm/Disarm the Zone	50
4.3.7 Set Arming/Disarming Schedule	51
4.3.8 Bypass Zone	52

4.3.9 Add Card	53
4.3.10 Add Keyfob	55
4.3.11 Check System Status (Zone Status/Communication Status)	55
4.3.12 Check Alarm Notification	56
Chapter 5 Operations	58
5.1 Arming	58
5.2 Disarming	59
5.3 Use the Keyfob	59
5.4 Use the Card	62
5.5 Use the Client Software	62
5.5.1 Accessing the Operation Page	62
5.5.2 Partition Operation	62
5.5.3 Zone Operating	63
5.6 Use the Web Client	64
5.6.1 Add/Edit/Delete Tag (Card)	64
5.6.2 Add/Edit/Delete Keyfob	65
5.6.3 Add/Edit/Delete User	66
5.6.4 Check Status	67
Appendix A. Trouble Shooting	68
A.1 Communication Fault	68
A.1.1 IP Conflict	68
A.1.2 Web Page is Not Accessible	68
A.1.3 Hik-Connect is Offline	68
A.1.4 Network Camera Drops off Frequently	68
A.1.5 Failed to Add Device on APP	68
A.1.6 Alarm Information is Not Reported to APP/4200/Alarm Center	69
A.2 Mutual Exclusion of Functions	69
A.2.1 Unable to Enter Registration Mode	69

Hybrid Security Control Panel User Manual

A.2.2 Unable to Enter RF Signal Query Mode	69
A.3 Zone Fault	69
A.3.1 Zone is Offline	69
A.3.2 Zone Tamper-proof	70
A.3.3 Zone Triggered/Fault	70
A.4 Problems While Arming	70
A.4.1 Failure in Arming (When the Arming Process is Not Started)	70
A.5 Operational Failure	70
A.5.1 Failed to Enter the Test Mode	70
A.5.2 The Alarm Clearing Operation on the Panel Does Not Produce the Alarm Clearing Report	71
A.6 Mail Delivery Failure	71
A.6.1 Failed to Send Test Mail	71
A.6.2 Failed to Send Mail during Use	71
A.6.3 Failed to Send Mails to Gmail	71
A.6.4 Failed to Send Mails to QQ or Foxmail	72
A.6.5 Failed to Send Mails to Yahoo	72
A.6.6 Mail Configuration	72
Appendix B. Input Types	74
Appendix C. Output Types	76
Appendix D. Event Types	77
Appendix E. Access Levels	78
Appendix F. SIA and CID Code	80

Chapter 1 System Description

Hybrid security control panel, containing onboard zones, supports wired/wireless alarm inputs and outputs expanding. It works with Wi-Fi, LAN, GPRS, and 3G/ 4G communication methods, as well as ISAPI, Ehome 5.0, and DC09 protocol. It is applicable to the scenarios of market, store, house, factory, warehouse, office, etc.

- Dual path communication of alarm events and other signals over LAN, PSTN, Wi-Fi (-W model), GPRS and 3G/4G utilizing a main and backup channel with configurable priority
- 4/8 on-board wired zones, and expandable with up to 20/64 wired zones
- Up to 20/64 wireless inputs, 20/64 wireless outputs, 8 keyfobs, 1 wired siren and 2 wireless sirens
- Camera accessing (only supported by DS-PHAXX-WXX)
- Pre-alarm (5 s/2 s) and post-alarm (2 s/5 s) recording for video verification to the alarm receiving email or mobile client
- Uploads alarm events to alarm receiving center or platform
- Supports arming/disarming via keypad, mobile client, iVMS-4200, SMS, and tag
- Configuration via web client, Hik-Connect, or iVMS-4200
- Pushes alarm notification via messages and email
- AES-128-bit data encryption
- LED indicator for indicating system status (-P model)
- Expandable PSTN, 3G/4G, and GPRS interface
- Supports RS-485 input and output expander
- Supports lithium battery (-P model) or storage battery (-M model)
- 1 manufacturer, 1 installer, 1 administrator, and 13 users (DS-PHA20)/45 users (DS-PHA64)

Chapter 2 Specifications

Model		DS-PHA20-P DS-PHA20-M DS-PHA64-M	DS-PHA20-W2M DS-PHA20-W2P DS-PHA64-W4M
Device connection	Wireless Detector	Up to 16/56	
	Wireless Output expander	Up to 8	
	Siren	1 wired siren (on-board connection) 2 wireless sirens	
	Keyfob	8	
Alarm input	Partition	4 (DS-PHA20) 8 (DS-PHA64)	
	Zone	4 on-board zones , and 16 wired/wireless zones expadable (DS-PHA20) 8 on-board zones, and 56 wired/wireless zones expadable (DS-PHA64)	
Alarm output	Alarm output	2 on-board outputs, and 18 wired/wireless outputs expadable (DS-PHA20) 4 on-board outputs, and 60 wired/wireless outputs expadable (DS-PHA64)	
Function	Scheduled arming/ disarming	Supported	
	SMS notification (with 3G/4G/GPRS module)	Supports up to 8 mobile phone numbers	
	Network camera accessing	N/A	2 (DS-PHA20) 4 (DS-PHA64)
Application & Protocol	Application	iVMS-4200 (client software) Hik-Connect (mobile client)	
	Protocol	ISAPI: Supports client software and web client Cloud P2P: Supports cloud P2P privacy protocol DC09: ARC accessible (CID/SIA)	

Hybrid Security Control Panel User Manual

Model		DS-PHA20-P DS-PHA20-M DS-PHA64-M	DS-PHA20-W2M DS-PHA20-W2P DS-PHA64-W4M
Network	Wired network	10M/100M Ethernet	
	Cellular Network (with 3G/4G/GPRS module)	Supports report push-notification to ARC & Cloud	
Wi-Fi	Standard	N/A	802.11b/g/n
	Encryption	N/A	64/128-bit WEP,WPA/WPA2,WPA-PSK/WPA2-PSK,WPS
	Configuration	N/A	AP Mode
	Distance	N/A	Indoor: ≤ 50 m Outdoor: ≤ 100 m
Interface & Component	TAMPER Switch	1, front cover tamper-proof	
	Network Interface	1, RJ45 10M/100M Ethernet Interface	
	Telephone Interface	1, PSTN expander interface	
	RS-485 Terminal	1, extended up to 20 inputs/outputs (with RS-485 module), and 9 wired keypads extendable (DS-PHA20) 1, extended up to 64 inputs/outputs (with RS-485 module), and 9 wired keypads extendable (DS-PHA64)	
	Siren Power Interface	1, 12V	
	Battery Interface	Lithium battery (-P model) Storage battery (-M model)	
User	User	Installer: 1 Administrator: 1 Manufacturer:1 Operator: 13 (DS-PHA20), 45 (DS-PHA64)	
Others	Auxiliary Power Supply	Plastic Case: 7.2W, current: 600mA Metal Case: 13W, current: 1000mA	
	Siren Output Power	Plastic Case: 5W, current: 400 mA Metal Case: 8W, current: 600 mA	

Hybrid Security Control Panel User Manual

Model		DS-PHA20-P DS-PHA20-M DS-PHA64-M	DS-PHA20-W2M DS-PHA20-W2P DS-PHA64-W4M
	RS-485 Device Output Power	Plastic Case: 7.2W, current: 600mA Metal Case: 13W, current: 1000mA	
	Alarm Output Rated Current	500 mA	
	Operation Temperature	-10 °C to 55 °C (-4 °F to +122 °F)	
	Operation Humidity	10% to 90% (No condensing)	
	Dimension (W × H × D)	Plastic Case: 220 mm (8.6") × 152 mm (6.0") × 31.5 mm(1.2") Metal Case: 351.4 mm (13.8") × 261.4 mm (10.3") × 93.3 mm (3.7")	

Chapter 3 Activation

In order to protect personal security and privacy and improve the network security level, you should activate the device the first time you connect the device to a network.

3.1 Activate Device via Web Browser

Use web browser to activate the device. Use SADP software or PC client to search the online device to get the IP address of the device, and activate the device on the web page.

Before You Start

Make sure your device and your PC connect to the same LAN.

Steps

1. Open a web browser and input the IP address of the device.



If you connect the device with the PC directly, you need to change the IP address of your PC to the same subnet as the device. The default IP address of the device is 192.0.0.64.

2. Create and confirm the admin password.



STRONG PASSWORD RECOMMENDED-We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

3. Click **OK** to complete activation.
4. Edit IP address of the device.
 - 1) Enter IP address modification page.
 - 2) Change IP address.
 - 3) Save the settings.

3.2 Activate Device via iVMS-4200

It is a PC client to manage and operate your devices. Security control panel activation is supported by the software.

Before You Start

- Get the client software from the supplied disk or the official website <http://www.hikvision.com/en/> . Install the software by following the prompts.
- The device and the PC that runs the software should be in the same subnet.

Steps

1. Run the client software.
2. Enter **Device Management** or **Online Device**.
3. Check the device status from the device list, and select an inactive device.
4. Click **Activate**.
5. Create and confirm the admin password of the device.



Caution

STRONG PASSWORD RECOMMENDED-We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

6. Click **OK** to start activation.
Device status will change to **Active** after successful activation.
7. Edit IP address of the device.
 - 1) Select a device and click **Modify Netinfo** at **Online Device**.
 - 2) Change the device IP address to the same subnet with your computer by either modifying the IP address manually or checking **DHCP**.
 - 3) Input the admin password of the device and click **OK** to complete modification.

3.3 Activate via SADP

SADP is a tool to detect, activate and modify the IP address of the device over the LAN.

Before You Start

- Get the SADP software from the supplied disk or the official website <http://www.hikvision.com/en/> , and install the SADP according to the prompts.
- The device and the PC that runs the SADP tool should be within the same subnet.

The following steps show how to activate a device and modify its IP address. For batch activation and IP addresses modification, refer to *User Manual of SADP* for details.

Steps

1. Run the SADP software and search the online devices.
2. Find and select your device in online device list.
3. Input new password (admin password) and confirm the password.

Chapter 4 Configuration

Configure the security control panel in the web client or the remote configuration page in client software.

4.1 Use the Client Software

Steps

1. Download, install and register to the client software.
2. Add device in **Control Panel** → **Device Management** → **Device** .

 **Note**

Set the device port No. as 80.

 **Note**

The user name and password when adding device are the activation user name and password.

3. Click **Remote Configuration** to enter the device configuration page after the device is completely added,

4.2 Use the Web Client

Steps

1. Connect the device to the Ethernet.
2. Search the device IP address via the client software and the SADP software.
3. Enter the searched IP address in the address bar.

 **Note**

When using mobile browser, the default IP Address is 192.168.8.1. The device must be in the AP mode.

 **Note**

When connecting the network cable with computer directly, the default IP Address is 192.0.0.64

4. Use the activation user name and password to login.

 **Note**

Refer to *Activation* chapter for the details.

4.2.1 Communication Settings

Wired Network

If the device is linked to the wired network, you can set the wired network parameters when you want to change the device IP address and other network parameters.

Steps

Note

The function is not supported by some device models.

1. In iVMS-4200 client software, enter the **Device Management** page.
2. Select the device in the Device for Management list, click **Remote Configuration**.
3. Click **Communication Parameters** → **Ethernet** to enter the Wired Network Parameters page.

Wired Network Settings

DHCP	<input type="checkbox"/>
IP Address	<input type="text" value="10.6.112.14"/>
Subnet Mask	<input type="text" value="255.255.255.0"/>
Gateway Address	<input type="text" value="10.6.112.254"/>
MAC Address	<input type="text" value="58:03:fb:b4:3b:6a"/>
DNS1 Server Address	<input type="text" value="8.8.8.8"/>
DNS2 Server Address	<input type="text" value="8.8.4.4"/>
HTTP Port	<input type="text" value="80"/>

Figure 4-1 Wired Network Settings Page

4. Set the parameters.
 - Automatic Settings: Enable **DHCP** and set the HTTP port.
 - Manual Settings: Disabled **DHCP** and set **IP Address**, **Subnet Mask**, **Gateway Address**, **DNS Server Address**.

Note

By default, the HTTP port is 80.

5. **Optional:** Set correct DNS server address if the device needs to visit Hik-Connect server via a domain name.

6. Click **Save**.

Wi-Fi

You can set the Wi-Fi parameters if there are secure and credible Wi-Fi networks nearby.

Steps

1. Click **Communication Parameters** → **Wi-Fi** to enter the Wi-Fi page.

Wi-Fi Access point WLAN

Status of STA/AP Swit...

Switch Mode: STA Mode

Wi-Fi

SSID Wi-Fi

Wi-Fi Password

Encryption Mode WPA2-personal

Network List

Name	Channel No.	Signal Strength	Encryption Mode	Operation
HIK-Office	1	88	WPA2-personal	Connect
OPPO R17	6	56	WPA2-personal	Connect
Wan-845939396	11	46	WPA2-personal	Connect

Figure 4-2 Wi-Fi Settings Page

2. Connect to a Wi-Fi.

- **Manually Connect:** Input the **SSID Wi-Fi** and **Wi-Fi Password**, select **Encryption Mode** and click **Save**.
- **Select from Network List:** Select a target Wi-Fi from the Network list. Click **Connect** and input Wi-Fi password and click **Connect**.

3. Click **WLAN** to enter the WLAN page.

Wi-Fi Access point **WLAN**

DHCP :	<input checked="" type="checkbox"/>
IP Address	<input type="text" value="0.0.0.0"/>
Subnet Mask	<input type="text" value="0.0.0.0"/>
Gateway Address	<input type="text"/>
MAC Address	<input type="text" value="00:95:69:f2:b6:a5"/>
DNS1 Server Address	<input type="text"/>
DNS2 Server Address	<input type="text"/>

Figure 4-3 WLAN Settings Page

4. Set IP Address, Subnet Mask, Gateway Address, and DNS Server Address.

 **Note**

If enable DHCP, the device will gain the Wi-Fi parameters automatically.

5. Click Save.

Cellular Network

Set the cellular network parameters if you insert a SIM card inside the device. By using the cellular network, the device can upload alarm notifications to the alarm center.

Before You Start

Insert a SIM card into the device SIM card slot.

Steps

1. Click **Communication Parameters** → **Cellular Data Network** to enter the Cellular Data Network Settings page.

Cellular Data Network Settings

Enable GPRS/3G/4G	<input checked="" type="checkbox"/>
Phone Number	<input type="text" value="*99***1#"/>
User Name	<input type="text"/>
Access Password	<input type="text"/>
APN	<input type="text"/>
MTU	<input type="text" value="1400"/>
PIN Code	<input type="text"/>
Data Usage Limit	<input checked="" type="checkbox"/>
Data Used This Month	<input type="text" value="0.0"/> M
Data Limited per Month	<input type="text" value="100"/> M

Figure 4-4 Cellular Data Network Settings Page

2. Enable Wireless Dial.
3. Set the cellular data network parameters.

Access Number

Input the operator dialing number.

User Name

Ask the network carrier and input the user name.

Access Password

Ask the network carrier and input the password.

APN

Ask the network carrier to get the APN information and input the APN information.

Data Usage Limit

You can enable the function and set the data threshold every month. If data usage is more than the configured threshold, an alarm will be triggered and uploaded to the alarm center and mobile client.

Data Used This Month

The used data will be accumulated and displayed in this text box.

4. Click **Save**.

Alarm Center

You can set the alarm center's parameters and all alarms will be sent to the configured alarm center.

Steps

1. Click **Communication Parameters** → **Alarm Receiving Center** to enter the Alarm Receiving Center page.

Alarm Receiving Center

Alarm Receiver Center	<input type="text" value="1"/>
Enable	<input checked="" type="checkbox"/>
Protocol Type	<input type="text"/>
Alarm Receiver Type	<input type="text" value="IP"/>
Alarm Receiver IP Addr...	<input type="text" value="0.0.0.0"/>
Port No.	<input type="text" value="0"/>
Account Code	<input type="text"/>

Figure 4-5 Alarm Receiving Center Parameters

2. Select the **Alarm Receiver Center** as **1** or **2** for configuration , and slide the slider to enable the selected alarm receiver center.

Note

Only if the alarm receiver center 1 is enabled, you can set the alarm receiver center 2 as the **backup channel** and edit the channel parameters.

3. Select the **Protocol Type** as **ADM-CID**, **EHome**, **SIA-DCS**, ***SIA-DCS**, ***ADM-CID**, or **PSTN-CID** to set uploading mode.
 - **ADM-CID** or **SIA-DCS**
You should select the **Alarm Receiver Type** as **IP** or **Domain name**, and enter the IP/domain name, port number, account code, timeout, re-upload times and heartbeat interval.

Alarm Receiving Center

Alarm Receiver Center	1
Enable	<input checked="" type="checkbox"/>
Protocol Type	SIA-DCS
Address Type	IP
Server Address	10.22.96.247
Port No.	6600
Account Code	1106
Transmission Mode	TCP
Retry Timeout Period	20 s
Attempts	2
Heartbeat Interval	300 s <input checked="" type="checkbox"/> Enable

Save

Figure 4-6 SIA-DCS

 **Note**

Set the heartbeat interval with the range from 10 to 3888000 seconds.

- **EHome**

You do not need to set the EHome protocol parameters.

Alarm Receiving Center

Alarm Receiver Center	1
Enable	<input checked="" type="checkbox"/>
Protocol Type	EHome
Address Type	IP
Server Address	10.22.96.247
Port No.	6600

Save

Figure 4-7 EHome

- ***SIA-DCS or *ADM-CID**

You should select the **Alarm Receiver Type** as **IP** or **Domain name**, and enter the IP/domain name, port number, account code, retry timeout period , attempts, heartbeat interval, encryption arithmetic, password length and secret key.

Alarm Receiving Center

Alarm Receiver Center	1
Enable	<input checked="" type="checkbox"/>
Protocol Type	*ADM-CID
Address Type	IP
Server Address	10.22.98.247
Port No.	6800
Account Code	1106
Transmission Mode	TCP
Retry Timeout Period	20 s
Attempts	2
Heartbeat Interval	300 s <input checked="" type="checkbox"/> Enable
Encryption Arithmetic	AES
Password Length	128
Secret Key	

Save

Figure 4-8 *ADM-CID

 **Note**

Set the heartbeat interval with the range from 10 to 3888000 seconds.

For encryption arithmetic: The panel support encryption format for information security according to DC-09, AES-128, AES-192 and AES-256 are supported when you configure the alarm center.

For the secret key: When you use an encrypted format of DC-09, a key should be set when you configure the ARC. The key would be issued offline by ARC , which would be used to encrypt the message for substitution security.

- **PSTN-CID**

You should enter the center name, center number, dialing times, and select communication protocol, transmission mode, receiver account.

Alarm Receiver Center	<input type="text" value="1"/>
Enable	<input checked="" type="checkbox"/>
Protocol Type	<input type="text" value="PSTN-CID"/>
Alarm Receiving Center	
Center Type	<input type="text" value="Center1"/>
Center Name	<input type="text"/>
Center Number	<input type="text"/>
Dialing Times	<input type="text" value="3"/> ✓
Communication Protocol	<input type="text" value="CID"/>
Transmission Mode	<input type="text" value="DTMF 10/S"/>
Receiver Account	<input type="text" value="0000"/> ✓

Figure 4-9 PSTN-CID

4. Click **Save**.

Notification Push

When an alarm is triggered, if you want to send the alarm notification to the client, alarm center, cloud or mobile phone, you can set the notification push parameters.

Steps

1. Click **Communication Parameters** → **Event Communication** .
2. Enable the target notification.

Alarms and Tamper

The device will push notifications when the zone alarm is triggered or the device tamper alarm is triggered or restored.

Life Safety Alarms

The device will push notifications when fire alarm, gas alarm, or medical alarm is triggered.

Maintenance and Faults

The device will push notifications when any status in the system is changed.

Panel Management Notification

The device will push notifications when the user operate the device.



If you want to send the alarm notifications to the mobile client, you should also set the **Mobile Phone Index**, **Mobile Phone Number** , and check the **Notification Type**.



For message notification in alarm receiving center, select the center index before settings.

3. Click **Save**.
4. Check the partitions you need in **Arming Permission**, **Disarming Permission** and **Alarm Clearing Permission**.

Result

Table 4-1 Options of Notifications

Option	Notification
iVMS-4200	Alarms and Tamper Life Safety Alarms Maintenance and Faults Panel Management Notification
Alarm Receiver Center	Alarm Receiver Center 1&2 Alarms and Tamper Life Safety Alarms Maintenance and Faults Panel Management Notification
Cloud	Alarms and Tamper Life Safety Alarms Maintenance and Faults Panel Management Notification
Mobile Phone	Mobile Phone Index 1 to 8 Mobile Phone Number Notification Type SMS Alarms and Tamper Life Safety Alarms Maintenance and Faults Operation Events

Note

You can arm/disarm/clear alarm via sending SMS. The number of the SIM card installed in the control panel is the receiver number.

The control message is **Command + Operation Type + Target** , and the details are show below.

For examples, command **00+1+1** indicates partition 1 disarming, and command **01+1+1** indicates partition 1 away arming.

Command	Operation Type	Target
2 Digits 00: Disarming 01: Away Arming 02: Stay Arming 03: Alarm Clearing	1 Digit 1: Partition Operation	No more than 3 Digits 0: All partition arming/ disarming/clearing Alarm 1: Partition 1 arming/ disarming/clearing Alarm ... 13: Partition 13 arming/ disarming/clearing Alarm ...

Hik-Connect

If you want to register the device to the Hik-Connect mobile client for remote configuration, you should set the Hik-Connect registration parameters.

Before You Start

- Connect the device to the network via wired connection, dial-up connection, or Wi-Fi connection.
- Set the device IP address, subnet mask, gateway and DNS server in the LAN.

Steps

1. Click **Communication Parameters** → **Hik-Connect Registration** to enter the Hik-Connect Registration Settings page.

Hik-Connect Adding Settings

Register to Hik-Connect

Hik-Connect Adding Status: Online

Custom Server Address:

Server Address:

Communication Mode:

Verification Code:

The password should contain 6 to 12 characters (it is recommended to be more than 8 characters and the combination of numeric and letter) .

Figure 4-10 Hik-Connect Registration Settings Page

2. Check Register to Hik-Connect.

 **Note**

By default, the device Hik-Connect service is enabled.

You can view the device status in the Hik-Connect server (www.hik-connect.com).

3. Enable Custom Server Address.

The server address is already displayed in the Server Address text box.

4. Select a communication mode from the drop-down list according to the actual device communication method.

Auto

The system will select the communication mode automatically according to the sequence of, wired network, Wi-Fi network, and cellular data network. Only when the current network is disconnected, will the device connect to other network.

Wired Network Priority

The wired network has the highest priority.

 **Note**

When the device supports cellular data network connection and the wired network is disconnected, it will connect to the cellular data network. When the wired network is

restored, only if the cellular data network is disconnected, does the device connect to the wired network.

Wired & Wi-Fi

The system will select wired network first. If no wired network detected, it will select Wi-Fi network.

Cellular Data Network

The system will select cellular data network only.

5. Optional: Change the authentication password.

Note

- By default, the authentication password is displayed in the text box.
 - The authentication password should contain 6 to 12 letters or digits. For security reasons, an 8-character password is suggested, which containing two or more of the following character types: uppercases, lowercases, and digits.
-


6. Click **Save**.

EHome

In this section, you can create an EHome account, and edit the IP address/domain name, port number.

Steps

1. Click **Communication Parameters** → **Ehome Registration** to enter the Ehome Registration Settings page.



The screenshot shows the 'Ehome Registration Settings' page. It features a list of configuration options on the left and their corresponding values or controls on the right. The 'Enable' option is a green toggle switch. The 'Ehome Protocol Version' is a dropdown menu set to 'EHome5.0'. The 'Alarm Receiver Type' is a dropdown menu set to 'IP'. The 'Alarm Receiver IP Addr...' is an empty text input field. The 'Port No.' is a text input field containing '7660'. The 'Registration Status' is a dropdown menu set to 'Offline'. The 'Device ID' is a text input field containing '000000'. The 'Ehome Login Password' is a text input field with a visibility icon. A red 'Save' button is located at the bottom of the form.

Setting	Value/Control
Enable	<input checked="" type="checkbox"/>
Ehome Protocol Version	EHome5.0
Alarm Receiver Type	IP
Alarm Receiver IP Addr...	
Port No.	7660
Registration Status	Offline
Device ID	000000
Ehome Login Password	

Save

Figure 4-11 EHome Registration

2. Slide the slider to enable EHome protocol.

3. Select the **Alarm Receiver Type** as **IP** or **Domain Name**.
4. Input IP address or domain name according to the alarm receiver type.
5. Input the port number for the protocol.



Note

By default, the port number for EHome is 7660.

6. Set an account, including the **Device ID** and **Ehome Login Password**.
7. Click **Save**.

NAT

Universal Plug and Play (UPnP™) is a networking architecture that provides compatibility among networking equipment, software and other hardware devices. The UPnP protocol allows devices to connect seamlessly and to simplify the implementation of networks in the home and corporate environments.

Enable the UPnP function, and you don't need to configure the port mapping for each port, and the device is connected to the Wide Area Network via the router.

Steps

1. Click **Communication Parameters** → **NAT** to enter the page.

The screenshot shows the NAT configuration interface. It includes a toggle for 'Enable UPnP' (checked), a dropdown for 'Mapping Type' (Manual), and input fields for 'HTTP Port' (80) and 'Service Port' (8000). Below these is a table with the following data:

Port Type	External Port	External IP Address	Internal Port	UPnP Status
HTTP Port	80	0.0.0.0	80	Inoperative
Service Port	8000	0.0.0.0	8000	Inoperative

A red 'Save' button is located at the bottom of the form.

Figure 4-12 NAT Settings

2. Check the checkbox to enable UPnP.
3. **Optional:** Select the mapping type as **Manual**
4. Set the HTTP port and the service port.
5. Click **Save** to complete the settings

What to do next

Enter the tasks the user should do after finishing this task (optional).

Set FTP to Save Video

You can configure the FTP server to save alarm video.

Steps

1. Click **Communication Parameters** → **FTP** to enter the page.
2. Configure the FTP parameters

FTP Protocol

Uploads files via FTP.

Server Address and Port

The FTP server address and corresponding port.

User Name and Password

The FTP user should have the permission to upload pictures. If the FTP server supports picture uploading by anonymous users, you can check Anonymous to hide your device information during uploading.

Directory Structure

The saving path of snapshots in the FTP server.

What to do next

Enter the tasks the user should do after finishing this task (optional).

4.2.2 Device Management

Zone

You can set the zone parameters on the zone page.

Click **Device Management** → **Zone** to enter the Zone page.

Wired Zone Settings

Steps

1. Select a wired zone and click  to enter the Zone Settings page.

Zone	1
Name	Zone 1
Zone Type	Instant
Sensitivity	500ms
Zone Resistor	2.2k
Detector Type	Other Detector
Stay Arming Bypass	<input type="checkbox"/>
Silent Alarm	<input type="checkbox"/>
Panel Video Channel No.	Not Link
Zone Tampered	Disable

OK Cancel

Figure 4-14 Wired Zone Settings

2. Edit the zone name.
3. Select a zone type.

Instant Zone

This Zone type will immediately trigger an alarm event when armed.

Delayed Zone

Exit Delay: Exit Delay provides you time to leave through the defense area without alarm.

Entry Delay: Entry Delay provides you time to enter the defense area to disarm the system without alarm.

The system gives Entry/Exit delay time when it is armed or reentered. It is usually used in entrance/exit route (e.g. front door/main entrance), which is a key route to arm/disarm via operating keyboard for users.

Note

You can set 2 different time durations in **Partition Management → Schedule & Timer** .

Follow Zone

The zone acts as delayed zone when it detects triggering event during system Entry Delay, while it acts as instant zone otherwise.

Perimeter Zone

The system will immediately alarm when it detects a triggering event after the system is armed. There is a configurable interval timer between the alarm activation and siren output "Siren Delay Time (Perimeter Alarm) 0 to 600 Seconds". This option allows you to check the alarm and cancel the siren output during the interval time in case of false alarm.

When the zone is armed, you can set the peripheral alarm delayed time in **Partition Management** → **Schedule & Timer** . You can also mute the siren in the delayed time.

Silent Panic Zone

This zone type is active 24hrs, it is used for Panic or HUD (Hold Up Devices) not smoke sensors or break glass detectors.

Panic Zone

The zone activates all the time. It is usually used in the sites equipped with panic button, smoke detector and glass-break detector.

Fire Zone

The zone activates all the time with sound/siren output when alarm occurs. It is usually used in fire hazardous areas equipped with smoke detectors and temperature sensors.

Gas Zone

The zone activates all the time with sound/siren output when alarm occurs. It is usually used in areas equipped with gas detectors (e.g., the kitchen).

Medical Zone

The zone activates all the time with beep confirmation when alarm occurs. It is usually used in places equipped with medical emergency buttons.

Timeout Zone

The zone activates all the time. The zone type is used to monitor and report the "ACTIVE" status of a zone, but it will only report and alarm this status after the programmed time has expired. (1 to 599) Seconds. It can be used in places equipped with magnetic contacts that require access but for only a short period (e.g., fire hydrant box's door or another external security box door)

Disabled Zone

Alarms will not be activated when the zone is triggered or tampered. It is usually used to disable faulty detectors .

4. Set the zone sensitivity and zone resistor.



Note

The resistor wired on the on-board zone should be the same as the resistor configured on this page.

5. Select a detector type.
6. Enable **Stay Arming Bypass**, or **Silent Alarm** according to your actual needs.

Note

Some zones do not support the function. Refer to the actual zone to set the function.

7. Select the panel video channel No. and zone tampering wiring mode.

8. Click **OK**.


Note

After setting the zone, you can enter **Status → Zone** to view the zone status.

Wireless Zone Settings

Steps

1. Select a wireless zone and click  to enter the Zone Settings page.



The screenshot shows a 'Zone Settings' dialog box with the following fields and controls:

Zone	25
Name	Zone 25
Zone Type	Instant
Detector Type	Other Detector
Stay Arming Bypass	<input checked="" type="checkbox"/>
Silent Alarm	<input checked="" type="checkbox"/>
Enroll Wireless Detector	<input checked="" type="checkbox"/>
Serial No.	
Panel Video Channel No.	Not Link
Module Name	Invalid
Wireless Device Discon...	1 h

At the bottom right, there are two buttons: a red 'OK' button and a grey 'Cancel' button.

Figure 4-15 Wireless Zone Settings

2. Edit the zone name.

3. Select a zone type. For details, see *Wired Zone Settings*.

4. Enable **Stay Arming Bypass**, **Silent Alarm** and **Enroll Wireless Detector**.

5. Enter the serial No. to enroll the detector.

6. Select the module name.

7. Enter the wireless device disconnection duration.
8. Click **OK**.

Note

After setting the zone, you can enter **Status → Zone** to view the zone status.

What to do next

Click **Zone → Zone Module**, you can see the zone module information including module status, module address, module channel No., and module type.

Relay

If you want to link the device with a relay output to output the alarm, set the output parameters.

Steps

1. Click **Device Management → Relay** to enter the Output page.




Figure 4-16 Wireless Output Module Settings

2. Click  and the Relay Settings window will pop up.
3. Edit the relay name, select a link event, and set the output delay time duration.
4. Click **OK**.

Note

After the relay is configured, you can click **Status → Relay** to view the output status.

Siren

The siren is enrolled to the control panel via the wireless receiver module, and the 868 Mhz wireless siren can be enrolled to the hybrid control panel via the wireless receiver that is at the address of 9.

Steps

1. Click **Device Management** → **Siren** to enter the Siren page.
2. Click  to enter the Siren Settings page.

- **Wired Siren**

Set the siren name and the linked event.





Figure 4-17 Wired Siren

- **Wireless Siren**

Enter the siren name and disconnection duration. Select the module name. Enable **Enroll Wireless Siren** and enter the serial No. of the detector.



Siren	2
Name	siren 2
Disconnection Duration	1 h
Volume	2
Module Name	Invalid
Enroll Wireless Siren	<input checked="" type="checkbox"/>
Serial No.	

OK Cancel

Figure 4-18 Wireless Siren

3. Click **OK**.



Note

After the siren is configured, you can click **Status → Siren** to view the siren status.

Keypad

The keypad is connected to the control panel via RS-485 wiring. You can refer to Hybrid Control Panel Quick Start Guide for wiring details.

Steps

1. Click **Control Device → Keypad** to enter the page.
2. Click  to enter the Keypad Settings page.
3. Set the keypad name.
4. Select the keypad linked partition.
5. Click **OK**.

Module

The wired module is connected to the control panel via RS-485 wiring. You can refer to the Hybrid Control Panel Quick Start Guide for details.

Steps

1. Click **Device Management → Module Information** to enter the page.

2. Click  to enter the module settings page.
3. Set the module name.
4. Click **OK**.

4.2.3 Partition Settings

Basic Settings

You can link zones to the selected partition.

Steps

1. Click **Partition Management** → **Basic Settings** to enter the page.




Figure 4-19 Partition Basic Information Management Page

2. Select a partition.
3. Check the **Enable One-Push Arming** to enable the One-Push Arming key on the keypad.
4. Check the check box in front of the zone to select zones for the partition.
5. Click **Save** to complete the settings.

Public Partition Settings

Definition Public partition is considered a special one which can be shared to other partitions. It is usually applied to manage or control the public area related with other areas controlled by other partitions in one building.

Steps

1. Click **Partition Management** → **Public Partition** to enter the page.




Figure 4-20 Public Partition Settings

2. Check the checkbox to enable the public partition function.

 **Note**

the default public partition is partition 1

3. Select partition(s) to link to the public partition in the list.

 **Note**

It is required to select at least a partition to link to the public partition.

4. Click **Save** to set the partition as public partition.

Schedule and Timer Settings

You can set the **Entry Delay 1** & **Entry Delay 2** time duration for the delayed zone type and the Exit Delay delayed time to exit the zone. You can also set the alarm schedule. The zone will be armed/disarmed according to the configured time schedule.

Steps

1. Click **Partition Management** → **Schedule & Timer** to enter the Schedule & Timer page.

Basic Settings Public Partition **Schedule & Timer**

Partition	<input type="text" value="Partition1"/>
Entry Delay 1	<input type="text" value="30"/> s
Entry Delay 2	<input type="text" value="60"/> s
Exit Delay	<input type="text" value="30"/> s
Enable auto Arming	<input type="checkbox"/>
Time	<input type="text" value="00:00"/>
Enable auto Disarm...	<input type="checkbox"/>
Time	<input type="text" value="00:00"/>
Late to Disarm	<input type="checkbox"/>
Time	<input type="text" value="00:00"/>
Weekend Exception	<input type="checkbox"/>
Siren Delay Time (Peri...	<input type="text" value="60"/> s
Alarm Duration	<input type="text" value="90"/> s

Figure 4-21 Schedule & Timer Settings

2. Select a partition.
3. Set time duration of **Delay 1**, **Delay 2**, or **Exit Delay** respectively.

Delay 1/Delay 2

If you have set the delayed zone, you can set the delayed time duration here.

Note

The available time duration range is from 5s to 600s.

Exit Delay

If you want to exit the zone without triggering the alarm, you can set the exit delay duration.

Note

The available time duration range is from 5 s to 600 s.

4. **Optional:** Set the following parameters according to actual needs.

Enable Auto Arming

Enable the function and set the arming start time. The zone will be armed according to the configured time.

 **Note**

The auto arming time and the auto disarming time cannot be the same.

 **Note**

The buzzer beeps slowly 2 minutes before the auto arming starts, and beeps rapidly 1 minute before the auto arming starts.

 **Note**

You can select to enable forced arming on the System Options page. While the function is enabled, the system will be armed regardless of the fault.

 **Note**

If the public partition is enabled, the partition 1 does not support auto arming.

Enable Auto Disarming

Enable the function and set the disarming start time. The zone will be disarmed according to the configured time.

 **Note**

The auto arming time and the auto disarming time cannot be the same.

 **Note**

If the public partition is enabled, the partition 1 does not support auto disarming.

Late to Disarm

Enable the function and set the time. If the alarm is triggered after the configured time, the person will be considered as late.

 **Note**

You should enable the Panel Management Notification function in **Communication Parameters** → **Event Communication** before enabling the Late to Disarm function.

Weekend Exception

Enable the function and the zone will not be armed in the weekend.

Siren Delay Time (Perimeter Alarm)

If you have set the perimeter zone, you can set the delayed time for the zone.

Note

The available time duration range is from 0 s to 600 s.

Alarm Duration

Set the time duration of the alarm.

Note

The available time duration range is from 1 s to 900 s.

5. Click **Save**.

4.2.4 Video Management

You can add 4 network cameras to the security control panel, and link the camera with the selected zone for video monitoring. You can also receive and view the event video via client and Email.

Add Cameras to the Security Control Panel

Steps

1. Click **Device Management** → **Channel** to enter the network camera management page.




Figure 4-22 Network Camera Management

2. Click **Add**, and enter the basic information of the camera, such as IP address and port No., and select the protocol type.
3. Enter the user name and password of the camera.
4. Click **OK**.

5. **Optional:** Click **Edit** or **Delete** to edit or delete the selected camera.

Link a Camera with the Zone

Steps

1. Click **Device Management** → **Zone** to enter the configuration page.
2. Select a zone that you wish to include video monitoring, and click the **Settings** icon.
3. Select the **Panel Video Channel No.**.
4. Click **OK**.

Set Email to Receive Alarm Video

You can send the alarm video or event to the configured email.

Steps

1. Click **Communication Parameters** → **Video Verification Events** to enter the page.

The screenshot shows the 'Video Verification Email Setting' configuration page. At the top, the title 'Video Verification Email Setting' is underlined in red. Below the title, there is a list of configuration items:

- Video Verification Events:** A green toggle switch is turned on.
- Sender Name:** An empty text input field.
- Sender:** An empty text input field.
- SMTP Server address:** An empty text input field.
- SMTP Port No.:** A text input field containing the number '25'.
- Encryption Type:** A dropdown menu with 'None' selected.
- Server Authentication:** A grey toggle switch is turned off.
- User Name:** An empty text input field.
- Password:** An empty text input field.
- Confirm Password:** An empty text input field.
- Receiver Name:** An empty text input field.
- Receiver:** An empty text input field.

At the bottom right of the form, there is a button labeled 'Receiver Address Test'. At the bottom center, there is a red button labeled 'Save'.

Figure 4-23 Set Email to Receive Alarm Video

2. Click the block to enable the function.
3. Enter the sender's information.
4. Enter the receiver's information.
5. Click **Receiver Address Test** and make sure the address is correct.
6. Click **Save**.

Set Video Parameters

Steps

1. Click **Video & Audio** → **Event Video Parameters** to enter the page.

Event Video Settings

Panel Video Channel No.	<input type="text"/>
Stream Type	<input type="text"/>
Bitrate Type	<input type="text"/>
Resolution	<input type="text"/>
Video Bitrate	<input type="text"/> Kbps
Length of Cached Vide...	<input type="text"/> s
Length of Cached Vide...	<input type="text"/> s

Save

Figure 4-24 Video Settings

2. Select a camera and set the video parameters.

Stream Type

Main Stream: Being used in recording and HD preview, it has a high resolution, code rate and picture quality..

Sub-Stream: It is used to transmit network and preview pictures as a video streaming with features of lower resolution, bit rate and picture quality.

Bitrate Type

Select the Bitrate type as constant or variable.

Resolution

Select the resolution of the video output

Video Bitrate

The higher value corresponds to the higher video quality, but the better bandwidth is required.

4.2.5 Permission Management

Add/Edit/Delete User

Administrator can add user to the security control panel, edit the user information, or delete the user from the security control panel. You can also assign different permissions to the new user.

Steps

1. Click **User Management** → **User** to enter the User Management page.
2. To compliant the EN requirement, slide the block to enable the setter and manufacturer .

Note

The default password of the setter is **setter12345**, and the default password of the manufacturer is **hik12345**. These codes will have to be changed when first connected.

3. Click **Add**.
4. Set the new user's information in the pop-up window, including the user type, the user name, and the password.




Figure 4-25 Add User Page

5. Set the keypad password (numeric, 4~6 characters).
6. Check the check boxes to set the user permission.
The user can only operate the assigned permissions.
7. Click **OK**.
8. **Optional:** Enable the user in the Enable User column to allow the enabled user operating the device.
9. **Optional:** Select an user and click **Edit** and you can edit the user's information and permission.
10. **Optional:** Delete a single user or check multiple users and click **Delete** to delete users in batch.

Note

The admin and the setter cannot be deleted.

Add/Edit/Delete Keyfob

You can add keyfob to the security control panel and you can control the security control panel via the keyfob. You can also edit the keyfob information or delete the keyfob from the security control panel.

Steps

1. Click **User Management** → **Keyfob** to enter the Keyfob Management page.




Figure 4-26 Keyfob Management

2. Click **Add** and press any key on the keyfob.
3. Set the keyfob linked device type and linked device No..
4. Click **OK**.
5. **Optional:** Click  to edit the keyfob information.
6. **Optional:** Delete a single keyfob or check multiple keyfobs and click **Delete** to delete the keyfobs in batch.

Add/Edit/Delete Tag (Card)

You can add tag to the security control panel and you can use the tag(card) to arm/disarm the zone. You can also edit the tag information or delete the tag from the security control panel.

Steps

1. Click **User Management** → **Card** to enter the management page.




Figure 4-27 Tag Management

2. Click **Add** to enter the adding page.
3. Select the linked keypad.
4. Click **OK** and the tag information will be displayed in the list.



Note

The tag supports at least 20-thousand serial numbers.

5. **Optional:** Click  and you can change the tag(card) name.
6. **Optional:** Delete a single tag(card) or check multiple tags(cards) and click **Delete** to delete cards in batch.


4.2.6 Maintenance

Test

The security control panel supports walk test function.

Steps

1. Enter **Maintenance** → **Test** → to enable the function.



2. Check the **Test** check box to start walk test.


3. Click **Save** to complete the settings.
4. Trigger the detector in each zone.
5. Check the test result.

Diagnosis

The control panel supports diagnosis of system, alarm, wireless device, Wi-Fi, and cloud platform

Steps

1. Enter **Maintenance** → **Diagnosis** .



2. Select system, alarm, wireless device, Wi-Fi, or cloud platform as the diagnosis module. Or you can select **Custom**, and enter the custom command (1~64) characters.
3. Click **Diagnosis** to start the operation.
4. View the diagnosis result in the information box.

Export File

You can export debugging file to the PC.

Steps

1. Click **Maintenance** → **Export File** to enter the page.




Figure 4-28 Export File Page

2. Check the check box to enable the function.
3. Click **Export** to save the debugging file in the PC.

4.2.7 System Settings

Authority Management

Set the authority options.

Click **System** → **System Options** to enter the Option Management page.

Forced Arming

If the option is enabled and there are active faults in a zone, the zone will be bypassed automatically.



Note

- You should disable the arming function in the Advanced Settings page. Or the forced arming function cannot be valid.
 - If Enable Arming is enabled, Forced Arming is only effective for Auto Arming.
-

System Faults

If the option is enabled, the device will upload the system fault report automatically.

Authority Advanced Settings

Set advanced authority parameters.

Click **System** → **System Options** → **Advanced Settings** to enter the Advanced Settings page.

You can set the following parameters:

Enable Arming

When you enable the function, during the device arming procedure, the system will check the configured fault checklist. When there is fault occurred during the arming procedure, the procedure will be stopped.



Note

PKG keypad and the keyfob do not support this function. If this function is enabled, the arming will fail if there is a fault. It is necessary to eliminate the fault or close the Enable Arming.

Fault Checklist

The system will check if the device has the faults in the checklist during the arming procedure.

Enable Arming with Fault

Check the faults in the Enable Arming with Fault list, and the device will not stop the arming procedure when faults occurred.

Arming Indicator Keeps Light

If the device applies EN standard, by default, the function is disabled. In this case, if the device is armed, the indicator will be solid blue for 5 s. And if the device is disarmed, the indicator will flash 5 times.

When the function is enabled, if the device is armed, the indicator will be on all the time. And if the device is disarmed, the indicator will be off.



Note

Only -P model supports this function.

Prompt Fault When Arming

If the device applies EN standard, by default, the function is disabled. In this case, the device will not prompt faults during the arming procedure.



Note

Only -P model supports this function.

Enable Early Alarm

If you enable the function, when the zone is armed and the zone is triggered, the alarm will be triggered after the delay time.



Note

The early alarm will be taken effect only after the delayed zone is triggered.

Delay

When the early alarm function is enabled, you should set the delay time. The alarm will be triggered after the configured delay time.

Fault Check

The system determines whether to check the faults listed on the page. The system will only check the fault that is selected.

Detect Network Camera Disconnection

If the option is enabled, when the linked network camera is disconnected, an alarm will be triggered.

Battery Supervision

If the option is enabled, when battery is disconnected or out of charge, the device will not upload events.

Wired Network Fault Check

If the option is enabled, when the wired network is disconnected or with other faults, the alarm will be triggered.

Wi-Fi Fault Check

If the option is enabled, when the Wi-Fi is disconnected or with other faults, the alarm will be triggered.

Cellular Network Fault Check

If the option is enabled, when the cellular data network is disconnected or with other faults, the alarm will be triggered.

SIM Card Fault Check

If the option is enabled, the alarm will be triggered for faults of the SIM card.

Telephone Line Cut Off Detection

If the option is enabled, the alarm will be triggered when the phone line connected to the PSTN module disconnects.

RS-485 Exception Detection

If the option is enabled, the alarm will be triggered when the RS-485 bus of device has exception.

AC Power Down Check Time

The system checks the fault after the configured time duration after AC power down.

The time duration should be set as 10 s.

Enrollment Method

Steps

1. Click **System** → **System Options** → **Adding Through** to enter the enrollment method page.




Figure 4-29 Enrollment Method

2. Click **Enter the Enrollment Mode**.

3. In the pop-up window, Select a RS-485 wireless receiver.
4. Select the wireless device type.
5. Click OK to finish the enrollment settings.

Time Settings

You can set the device time zone, synchronize device time, and set the DST time. The device supports time synchronization via **Hik-Connect** server.

Time Management

Click **System** → **Date and Time** to enter the Time Management page.

You can select a time zone from the drop-down list.

You can synchronize the device time manually with NTP. Check the check box of **NTP Time Sync.**, enter the server address and port No., and set the synchronization interval.

You can synchronize the device time manually. Or check **Sync. with Computer Time** to synchronize the device time with the computer time.

DST Management

Click **System** → **Date and Time** → **DST Management** to enter the Time Management page.

The screenshot shows the 'DST Management' configuration interface. It features a breadcrumb trail: **Time Management** > **DST Management**. The main settings are as follows:

- Time Zone:** A dropdown menu showing '(GMT+00:00) Dublin, Edinburgh, London'.
- Time Synchronization:**
 - Synchronization Mode:** Two radio buttons are present: 'NTP Time Sync.' (unselected) and 'Manual Time Sync.' (selected).
 - Date and Time:** A text input field containing '2018-12-10 09:50:27'.
 - PC Sync:** A text input field containing '2018-12-10 09:49:48' with a calendar icon to its right. To the right of this field is a checkbox labeled 'Sync. With Computer Time', which is currently unchecked.
- Save:** A prominent red button at the bottom center of the form.

Figure 4-31 DST Management

You can enable the DST and set the DST bias, DST start time, and DST end time.

Security Settings

SSH Settings

Enable or disable SSH (Secure Shell) according to your actual needs.

Click **System** → **Security** → **SSH Settings** to enter the SSH Settings page and you can enable or disable the SSH function.

Locking User Settings

Set user locking. You can view the locked user or unlock a user and set the user locked duration.

Steps

1. Click **System** → **Security** → **Locking User Settings** to enter the Locking User Settings page.
2. Set the following parameters.

Max. Failure Attempts

If the user continuously input the incorrect password for more than the configured times, the account will be locked.



The administrator has two more attempts than the configured value.

Locked Duration

Set the locking duration when the account is locked.



The available locking duration is 5s to 1800s.

3. Click  to unlock the account or click **Unlock All** to unlock all locked users in the list.
4. Click **Save**.

Module Lock Settings

Set the module locking parameters, including the Max Failure Attempts, and locked duration. The module will be locked for the programmed time duration, once the module authentication has failed for the amount of configured times.

Steps

1. Click **System** → **Security** → **Module Lock Settings** to enter the Module Lock Settings page.
2. Select a module from the list, and click the **Operation** icon.
3. Set the following parameters of the selected module.

Max. Failure Attempts

If a user continuously tries to authentication a password for more than the configured attempts permitted, the keypad will be locked for the programmed duration.

Locked Duration

Set the locking duration when the keypad is locked. After the configured duration, the keypad will be unlocked.

4. Click **OK**.
5. **Optional:** Click the **Lock** icon to unlock the locked module.

SSH Settings Locking User Settings **Module Locking Settings**

No.	Device Type	Max. Failure Attempts	Locked Duration	Status	Operation
1	Keypad	3	90	Unlocked	
2	Keypad	3	90		
3	Keypad	3	90	Unlocked	
4	Keypad	3	90	Unlocked	

Figure 4-32 Module Lock Settings

System Maintenance

You can reboot the device, restore default settings, import/export configuration file, or upgrade the device remotely.

Select the device and click **Remote Configuration** in the client software, or enter the device IP address in the address bar of the web browser. Click **System** → **System Maintenance** to enter the Upgrade and Maintenance page.

Reboot

Click **Reboot** to reboot the device.

Restore Default Settings

Click **Partly Restore** to restore all parameters except for admin user information, wired network, Wi-Fi network, detector information, and peripheral information to default ones.

Click **Restore All** to restore all parameters to the factory settings.

Import Configuration File

Click **View** to select configuration file from the PC and click **Import Configuration File** to import configuration parameters to the device.

Export Parameters

Click **Export Configuration File** to export the device configuration parameters to the PC.

Upgrade File

Click **View** to select an upgrade file from the PC and click **Upgrade** to upgrade the device remotely.



Note

Do not power off when the device is upgrading.

Local Log Search

You can search the log on the device.

Click **System** → **Log** to enter the Local Log Search page.

No.	Operation Time	Major Type	Minor Type	Local/Remote Operation User	Remote Host Address	Operation Method	Parameters
-----	----------------	------------	------------	-----------------------------	---------------------	------------------	------------

Figure 4-34 Local Log Search Page

Select a major type and a minor type from the drop-down list, set the log start time and end time and click **Filter**. All filtered log information will be displayed in the list.

You can also click **Reset** to reset all search conditions.

4.2.8 Check Status

After setting the zone, repeater, and other parameters, you can view their status.

Click **Status**. You can view the status of zone, relay, siren, battery, communication, and repeater.

- Zone: You can view the zone status, alarm status, detector battery capacity, and signal strength.
- Siren: You can view siren status, battery status, and signal strength.
- Relay: You can view relay status, battery status, and signal strength.
- Battery: You can view the battery charge.
- Communication: You can view the wired network "STATUS", Wi-Fi status, Wi-Fi signal strength, cellular network status, used data, and cloud connection status.

4.3 Use Mobile Client

4.3.1 Download and Login the Mobile Client

Download the Hik-Connect mobile client from Google Play (for Android) or App store (for iOS) and login the client before operating the security control panel.

Steps

1. Search and download Hik-Connect mobile client from Google Play (for Android) or App Store (for iOS).
2. **Optional:** Register a new account if it is the first time you use the Hik-Connect mobile client.

Note

For details, see *User Manual of Hik-Connect Mobile Client*.

3. Run and login the client.

4.3.2 Add Control Panel to the Mobile Client

Add a control panel to the mobile client before other operations.

Steps

1. Power on the control panel.
 2. Select adding type.
 - Tap  → **Scan QR Code** to enter the Scan QR code page. Scan the QR code on the control panel.
-

Note

Normally, the QR code is printed on the label stuck on the back cover of the control panel.

- Tap  → **Manual Adding** to enter the Add Device page. Input the device serial No. with the Hik-Connect Domain adding type.
3. Connect to a network.
 - 1) Tap **Connect to a Network**.




Figure 4-35 Connect to a Network Page

- 2) Tap **Wireless Connect** on the Select Connection Type page.
 - 3) Follow the instructions on the Turn on Hotspot page and change the control panel to the AP mode. Tap **Next**.
-

Note

You need to remove the rear panel of the device and the AP/STA switch is on the back of the device.

- 4) Select a stable Wi-Fi for the device to connect and tap **Next**.

 **Note**

Make sure the device and the mobile phone are connect to the same Wi-Fi.

4. Follow the instructions on the Device's Wi-Fi page and connect the mobile phone with the control panel via wireless connection.

 **Note**

Select **HAP-Device Serial No.** as the hotspot and enter the hotspot password. By default, the password is **AP + Device Verification Code**. The verification code is normally printed on the device label.

5. Return to the mobile client and create a device password for device activation.

 **Note**

We highly recommend you to create a strong password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

6. **Optional:** If you add the control panel by entering its serial No., you should enter the device verification code and tap **OK**.

 **Note**

By default, the verification code is printed on the device label.

7. Follow the instructions and change the control panel to the Station mode. Tap **Next**.

 **Note**

You need to remove the rear panel of the device and the AP/STA switch is on the back of the device.

8. When the control panel adding is completed, tap **Finish**.

The control panel is listed on the Hik-Connect page.

4.3.3 Add Peripheral to the Control Panel

It is required to enter the activation name and the password login the control panel after it being added. The tampering alarm will not be detected within 5 minutes after you login the device as a setter and does not operate the device.

Before You Start

Make sure the control panel is disarmed.

Steps

Note

Some control panel models do not support add zones or wireless devices remotely. You should add them to the control panel directly. For details, see the user manual of the wireless device.

1. Tap  to enter the Scan QR Code page.
 2. Scan the peripheral's QR code to add the peripheral.
 3. Select a peripheral type, and create a name for the peripheral.
-

Note

- When the adding peripheral is a detector, the detector will be linked to the zone. You can view the detector information in the Zone tab.
 - Up to 32 detectors can be linked to the zone.
-

The added peripheral will be listed in the Zone tab or the Wireless Device tab.

Note

One of the most important factors for a reliable wireless installation is the signal strength between a wireless device and the panel. If a device is out of range it will not be able to send events to the control panel therefore it is recommended that a signal strength test is performed before fixing devices into place. The control panel has advanced signal strength mechanism that operates by monitoring all inputs/bells on the web browser. The page will need to be re-freshed every time for a new test. See also Appearance-Function Button.

When performing a signal strength test it is recommended that the system is tested in the 'worst case scenario' for example with all doors and windows closed.

4.3.4 Add a Camera to the Zone

You can link a camera to the zone to monitor the zone. You can view the alarm videos when an alarm is triggered.

Before You Start

Make sure you have installed the camera in the target zone and the camera has connected the same LAN as the security control panel's.

Steps

1. Tap a security control panel on the Hik-Connect page and tap **Zone** to enter the zone list page.
2. Select a zone to enter the zone settings page.
3. Tap **Link Camera** to enter the Link Camera page.




Figure 4-36 Link Camera Page

4. Select a camera in the available cameras, and tap **Link**.

The selected camera will be linked to the zone. The icon  will be displayed on the right of the zone in the zone list. Tap the icon to view the zone live video.

4.3.5 Set Zone

After the detector is added, you can set the zone, including the zone name, the zone type, zone bypass, linked camera, stay/away status, the siren, and the silent zone. You can also view the detector serial No. (only device in 433 HMz) and the detector type of the zone.

Steps

1. Tap a zone in the Partition page to enter the zone settings page.
2. Set the following parameters as you desired.

Detector Type

Select a detector type of the zone from the list

Zone Type

Select a zone type from the zone type list.

Zone Bypass

Enable the function and the zone will be bypassed. No alarm will be received while the zone is bypassed.

Link Camera

You can link the zone to cameras. When an alarm is triggered, you can monitor the zone via the linked cameras.

4.3.6 Arm/Disarm the Zone

Arm or disarm the zone manually as you desired.

On the **Hik-Connect** page, tap a security control device to enter the control panel management page. Tap **Away/Stay/Disarm** to control the partition's status.

You can also tap **Clear Alarm** to clear the alarm when an alarm is triggered.




Figure 4-37 Control Panel Management Page

4.3.7 Set Arming/Disarming Schedule

Set the arming/disarming schedule to arm/disarm a particular zone automatically.

Tap a security control panel to enter the control page and tap  or  to enter the Settings page.

Enable the auto arm/disarm function and set the auto arm time/auto disarm time. You can also set the late to disarm time, entry delay time, exit delay time, and siren delay time.




Figure 4-38 Arming or Disarming Schedule Page

4.3.8 Bypass Zone

When the partition is armed, you can bypass a particular zone as you desired.

Before You Start

Link a detector to the zone.

Steps

1. Select a zone in the Zone tab of the Partition page to enter the settings page.
2. Select a zone and enter the Settings page.




Figure 4-39 Zone Settings Page

3. Enable **Zone Bypass** and the zone will be in the bypass status.

The detector in the zone does not detect anything and you will not receive any alarm from the zone.

4.3.9 Add Card

You can add card to the control panel. Use the card to arm, disarm, or clear alarm.

Steps

1. Select a control panel on the Hik-Connect page to enter the control panel management page.




Figure 4-40 Control Panel Management Page

2. Tap  → **Card/Tag Management** to enter the Card/Tag Management page.

3. Tap .
4. When hearing the voice prompt "Swipe Card", you should present the card on the control panel card presenting area.
When hearing a beep sound, the card is recognized.
5. Create a card alias and tap **Finish**.



Note

The alias should contain 1 to 32 characters.

The card is displayed in the Card/Tag Management page.

4.3.10 Add Keyfob

You can add keyfobs to the control panel and control partition arming/disarming status. You can also clear alarm when an alarm is triggered.

Steps



Note

Make sure the keyfob's frequency is the same as the control panel's.

1. Tap  to enter the Add Keyfob page.
2. Follow the instruction on the page and press any key on the keyfob to add.
3. Create a name for the keyfob and tap **Finish**.
The keyfob is listed in the Wireless Device page.
4. **Optional:** You can view the keyfob's serial No. and you can also delete it.

4.3.11 Check System Status (Zone Status/Communication Status)

You can view the zone status and the communication status via the mobile client.

View Zone Status

In the Partition page, tap Zone to enter the Zone tab. You can view the each zone's status in the list.

Communication Mode

Tap  to enter the control panel settings page. You can view the device communication status, including the battery, Ethernet network, Wi-Fi, mobile network, and data usage.

4.3.12 Check Alarm Notification

When an alarm is triggered, and you will receive an alarm notification. You can check the alarm information from the mobile client.

Before You Start

- Make sure you have linked a zone with a detector.
- Make sure the zone is not bypassed.
- Make sure you have not enabled the silent zone function.

Steps

1. Tap **Notification** in the Hik-Connect page to enter the page.




Figure 4-41 Notification

All alarm notifications are listed in Message page.

2. Select an alarm and you can view the alarm details.



Figure 4-42 Notification Details

- 3. Optional:** If the zone has linked a camera, you can view the playback when the alarm is triggered.

Chapter 5 Operations

You can use the client keyfob, card, client software, or mobile client to do arming, disarming, bypass, and zone disabling.

5.1 Arming

You can use keypad, keyfob, card, client software, mobile client to arm your system. After the arming command is sending to control panel, the sytem will check the detector status. If the detector is in fault, you will need to choose whether to arm the system with fault. While the system is armed, the control panel will prompt the result in 5s, and upload the arming report.




Figure 5-1 Arming Process

Access level of Arming

The user in level 2 or 3 has the permission to arm or partly arm the system.

Arming Indication

The arming/disarming indicator keeps solid blue for 5s.

Reason of Arming Failure

- Intrusion detector triggered (excepts the detector on the exit route).
- Panic alarm device triggered.
- Tampering alarm occurred.
- Communication exception
- Mian power supply exception
- Backup battery exception
- Alarm receiving fault
- Siren fault
- Low battery of the keyfob
- Others

Arming with Fault

While the arming is stopped with fault, user in level 2 has the permission to arm the system with fault (forced arming).

Fored arming only taks effect on the current arming operation.

The forced arming operation will be record in the event log.

5.2 Disarming

You can disarm the system with keypad, keyfob, card, client software, or mobile client.

Disarming Indication

The arming/disarming indicator flashes 30s while the user successfully disarm the system through the entry/exit route.

The system will report the disarming result after the operation completed.

Entry Delay Duration

Set the entry delay duration within 45s to compliant the EN requirement.

Early Alarm

If either the intrusion or tampering alarm occurs on the enter/exit route when the control panel is in the status of entry delay, the control panel then enters the early alarm mode.

The early alarm duration can be set (> 30s).

The control panel will reports the alarm only if the alarm event lasts over the duration of early alarm with the addition of entry delay.

5.3 Use the Keyfob

The keyfod is used for away arming, stay arming, disarming, panic alarm, and clearing alarm.




Figure 5-2 Type I Keyfob

Table 5-1 Type I Keyfob Keys

No.	Description
1	Indicator Green: Successful Operation Red: Press the Key
2	Away Arming
3	Clearing Alarm
4	Stay Arming
5	Disarming
6	Panic Alarm (Duress Alarm) Hold the key for 2 seconds, an alarm report will be send to the alarm center secretly without alerting.




Figure 5-3 Type II Keyfob

Table 5-2 Type II Keyfob Keys

No.	Description
1	Arming (Lock)
2	Disarming(Unlock)
3	Combo-Function Key

Custom Combination Functions (except Arming + II and Disarming + I) : Away Arming, Stay Arming, Disarming, Panic Alarm, Clearing Alarm, Fault Inspection, and Arming Status Check.

The following table shows the keyfob operation and responded indications.

Table 5-3 Type II Keyfob Operations and Indications

Keyfob Operation Result	Indication
Armed	Red LED Flashes Once
Arming Failed	Green LED Flashes Once
Arming	Green LED Flashes 9 Times
No Arming Permission	Yellow LED Flashes 4 Times
Fault Checking Finished	Yellow LED Flashes 4 Times
Alarm Cleared	Green LED Flashes Once
No Permission for Clearing Alarm	Yellow LED Flashes 4 Times
Disarmed	Green LED Flashes Once
No Disarming Permission	Yellow LED Flashes 4 Times
Panic Alarm Uploaded	Green LED Flashes Once
No Panic Alarm Permission	Yellow LED Flashes 4 Times

5.4 Use the Card

It is possible to arm or disarm the system with the card.

While the system is not armed, present a valid card to the control panel to arm the system.

While the system is armed, present a valid card to the control panel to disarm the system.

5.5 Use the Client Software

Steps

1. Download, install and register to the client software.
2. Add device in **Control Panel** → **Device Management** → **Device** .

Note

Set the device port No. as 80.

Note

The user name and password when adding device are the activation user name and password.

3. Click **Remote Configuration** to enter the device configuration page after the device is completely added,

5.5.1 Accessing the Operation Page

Control partitions and it's related zones in the **Security Control Panel** module.

Note

If there is no **Security Control Panel** displayed on the **Control Panel** page, click **Selecting Modules**, and select **Security Control Panel**

5.5.2 Partition Operation

In the **Security Control Panel** module, you can control the selected partition , such as away arming, stay arming, instant arming, disarming, clearing alarm, group bypass, and group bypass restoring.




Figure 5-4 Partition Operation

Click **Edit** to edit the partition name and display options.




Figure 5-5 Editing Partition Information

5.5.3 Zone Operating

Click **Linked Zone** in the partition list of the **Security Control Module**. You can control the selected partition related zones, such as arming, disarming, bypass, or bypass restoring.




Figure 5-6 Zone Operation

5.6 Use the Web Client

Steps

1. Connect the device to the Ethernet.
2. Search the device IP address via the client software and the SADP software.
3. Enter the searched IP address in the address bar.

Note

When using mobile browser, the default IP Address is 192.168.8.1. The device must be in the AP mode.

Note

When connecting the network cable with computer directly, the default IP Address is 192.0.0.64

4. Use the activation user name and password to login.

Note

Refer to *Activation* chapter for the details.

5.6.1 Add/Edit/Delete Tag (Card)

You can add tag to the security control panel and you can use the tag(card) to arm/disarm the zone. You can also edit the tag information or delete the tag from the security control panel.

Steps

1. Click **User Management** → **Card** to enter the management page.




Figure 5-7 Tag Management

2. Click **Add** to enter the adding page.
3. Select the linked keypad.
4. Click **OK** and the tag information will be displayed in the list.



Note

The tag supports at least 20-thousand serial numbers.

5. **Optional:** Click  and you can change the tag(card) name.
6. **Optional:** Delete a single tag(card) or check multiple tags(cards) and click **Delete** to delete cards in batch.

5.6.2 Add/Edit/Delete Keyfob

You can add keyfob to the security control panel and you can control the security control panel via the keyfob. You can also edit the keyfob information or delete the keyfob from the security control panel.

Steps

1. Click **User Management** → **Keyfob** to enter the Keyfob Management page.




Figure 5-8 Keyfob Management

2. Click **Add** and press any key on the keyfob.
3. Set the keyfob linked device type and linked device No..
4. Click **OK**.
5. **Optional:** Click  to edit the keyfob information.
6. **Optional:** Delete a single keyfob or check multiple keyfobs and click **Delete** to delete the keyfobs in batch.

5.6.3 Add/Edit/Delete User

Administrator can add user to the security control panel, edit the user information, or delete the user from the security control panel. You can also assign different permissions to the new user.

Steps

1. Click **User Management** → **User** to enter the User Management page.
2. To compliant the EN requirement, slide the block to enable the setter and manufacturer .

Note

The default password of the setter is **setter12345**, and the default password of the manufacturer is **hik12345**. These codes will have to be changed when first connected.

3. Click **Add**.
4. Set the new user's information in the pop-up window, including the user type, the user name, and the password.

Add User [X]

User Information

User Type: Operator

User Name: []

Password: []

The valid password (8 to 16 characters) should contain two or more of the following character types: numeric, lowercase, uppercase, and special character.

Confirm Password: []

Keypad Password: []

User Permission

Figure 5-9 Add User Page

5. Set the keypad password (numeric, 4~6 characters).
6. Check the check boxes to set the user permission.
The user can only operate the assigned permissions.
7. Click **OK**.
8. **Optional:** Enable the user in the Enable User column to allow the enabled user operating the device.
9. **Optional:** Select an user and click **Edit** and you can edit the user's information and permission.
10. **Optional:** Delete a single user or check multiple users and click **Delete** to delete users in batch.

 **Note**

The admin and the setter cannot be deleted.

5.6.4 Check Status

After setting the zone, repeater, and other parameters, you can view their status.

Click **Status**. You can view the status of zone, relay, siren, battery, communication, and repeater.

- Zone: You can view the zone status, alarm status, detector battery capacity, and signal strength.
- Siren: You can view siren status, battery status, and signal strength.
- Relay: You can view relay status, battery status, and signal strength.
- Battery: You can view the battery charge.
- Communication: You can view the wired network "STATUS", Wi-Fi status, Wi-Fi signal strength, cellular network status, used data, and cloud connection status.

Appendix A. Trouble Shooting

A.1 Communication Fault

A.1.1 IP Conflict

Fault Description:

IP that the panel automatically acquired or set is same as other devices, resulting in IP conflicts.

Solution:

Search the current available IP through ping. Change the IP address and log in again.

A.1.2 Web Page is Not Accessible

Fault Description:

Use browser to access web pages and display Inaccessible.

Solutions:

1. Check whether the network cable is loose and the panel network is abnormal.
2. The panel port has been modified. Please add a port to the web address for further access.

A.1.3 Hik-Connect is Offline

Fault Description:

The web page shows that the Hik-Connect is offline.

Solution:

Network configuration of the panel is error, unable to access extranet.

A.1.4 Network Camera Drops off Frequently

Fault Description:

System reports multiple event logs of IPC disconnection and connection.

Solution:

Check whether the network communication or camera live view is proper.

A.1.5 Failed to Add Device on APP

Fault Description:

When using APP to add devices, it is prompted that the device fails to be added, the device could not be found, etc.

Solution:

Check the web page: whether the Hik-Connect is offline.

A.1.6 Alarm Information is Not Reported to APP/4200/Alarm Center

Fault Description:

After the alarm is triggered, the app/4200/ alarm center does not receive the alarm message.

Solution:

"Message push" - "alarm and tamper-proof notice" is not enabled. You should enable "alarm and tamper-proof notice".

A.2 Mutual Exclusion of Functions

A.2.1 Unable to Enter Registration Mode

Fault Description:

Click the panel function key, and prompt key invalid.

Solution:

The panel is in "AP" mode. Switch the panel to "station" mode, and then try to enter the registration mode again.

A.2.2 Unable to Enter RF Signal Query Mode

Fault Description:

Double-click the host function key, and the prompt button invalid.

Solution:

The panel is in "AP" mode. Solution: switch the panel to "station" mode, and then try to enter the RF signal query mode again.

A.3 Zone Fault

A.3.1 Zone is Offline

Fault Description:

View status of zones which displays offline.

Solution:

Check whether the detector reports undervoltage. Replace the detector battery

A.3.2 Zone Tamper-proof

Fault Description:

View status of zones which displays tamper-proof.

Solution:

Make tamper-proof button of the detector holden.

A.3.3 Zone Triggered/Fault

Fault Description:

View status of zones which displays triggered/fault.

Solution:

Reset the detector.

A.4 Problems While Arming

A.4.1 Failure in Arming (When the Arming Process is Not Started)

Fault Description:

When the panel is arming, prompt arming fails.

Solution:

The panel does not enable "forced arming", and when there is a fault in the zone, the arming will fail. Please turn on the "forced arming" enable, or restore the zone to the normal status.

A.5 Operational Failure

A.5.1 Failed to Enter the Test Mode

Fault Description:

Failed to enable test mode, prompting "A fault in the zone".

Solution:

Zone status, alarm status or zone power is abnormal.

A.5.2 The Alarm Clearing Operation on the Panel Does Not Produce the Alarm Clearing Report

Fault Description:

The alarm clearing operation on the panel does not produce the alarm clearing report.

Solution:

In the absence of alarm, no report will be uploaded for arm clearing.

A.6 Mail Delivery Failure

A.6.1 Failed to Send Test Mail

Fault Description:

when configure the mail information, click "test inbox" and prompt test fails.

Solution:

Wrong configuration of mailbox parameters. Please edit the mailbox configuration information, as shown in table 1/1.

A.6.2 Failed to Send Mail during Use

Fault Description:

Check the panel exception log. There is "mail sending failure".

Solution:

The mailbox server has restricted access. Please log in to the mailbox to see if the mailbox is locked.

A.6.3 Failed to Send Mails to Gmail

Fault Description:

The receiver's mailbox is Gmail. Click "Test Inbox" and prompt test fails.

1. Google prevents users from accessing Gmail using apps/devices that do not meet their security standards.

Solution:

Log in to the website (<https://www.google.com/settings/security/lesssecureapps>), and "start using access of application not safe enough". The device can send mails normally.

2. Gmail does not remove CAPTCHA authentication.

Solution: Click the link below, and then click "continue" (<https://accounts.google.com/b/0/displayunlockcaptcha>).

A.6.4 Failed to Send Mails to QQ or Foxmail

Fault Description:

The receiver's mailbox is QQ or foxmail. Click "Test Inbox" and prompt test fails.

1. Wrong QQ account or password.

Solution:

the password required for QQ account login is not the password used for normal login. The specific path is: Enter the email account → device → account → to generate the authorization code, and use the authorization code as the login password.

2. SMTP login permission is needed to open.

A.6.5 Failed to Send Mails to Yahoo

Fault Description:

The receiver's mailbox is yahoo. Click "test inbox" and prompt test fails.

1. The security level of mailbox is too high.

Solution:

Go to your mail account and turn on "less secure sign-in".

A.6.6 Mail Configuration

Table A-1 Mail Configuration

Mail Type	Mail Server	SMTP Port	Protocols Supported
Gmail	smtp.gmail.com	587	TLS/STARTTLS (TLS)
Outlook	smtp.office365.com	587	STARTTLS (TLS)
Hotmail	smtp.office365.com	587	STARTTLS (TLS)
QQ	smtp.qq.com	587	STARTTLS (TLSv1.2)
Yahoo	smtp.mail.yahoo.com	587	STARTTLS (TLSv1.2)
126	smtp.126.com	465	SSL/TLS

Mail Type	Mail Server	SMTP Port	Protocols Supported
Sina	smtp.sina.com	25/465/587	SSL/TLS/STARTTLS (SSL/TLS)

 **Note**

About mail configuration:

- SMTP port
Default to use port 25 without encryption, or using port 465 if SSL/TLS is used. Port 587 is mainly used for STARTTLS protocol mode.
The STARTTLS protocol mode that is usually used by default when selecting TLS.
- User name
User name of Outlook and Hotmail require full names, and other email require a prefix before @.

Appendix B. Input Types

Table B-1 Input Types

Input Types	Operations
Instant Zone	<p>The system will immediately alarm when it detects triggering event after system armed.</p> <p>Audible Response Trigger the system sound and siren.</p> <p>Voice Prompt: Zone X alarm.</p>
Perimeter Zone	<p>The system will immediately alarm when it detects triggering event after system armed.</p> <p>Audible Response: Trigger the system sound and siren. There is a configurable interval between alarm and siren output, which allows you to check the alarm and cancel the siren output during the interval.</p> <p>Voice Prompt: Zone X perimeter alarm.</p>
Delayed Zone	<p>The system provides you time to leave through or enter the defense area without alarm.</p> <p>Audible Response: Trigger the system sound and siren.</p> <p>Voice Prompt: Zone X alarm.</p>
Follow Zone	<p>The zone acts as delayed zone when it detects triggering event during system Entry Delay, while it acts as instant zone otherwise.</p> <p>Audible Response: Trigger the system sound and siren.</p> <p>Voice Prompt: Zone X follow alarm.</p>
24H Silence Zone	<p>The zone activates all the time without any sound/siren output when alarm occurs.</p> <p>Audible Response: No system sound (voice prompt or siren).</p>
Panic Zone	<p>The zone activates all the time.</p> <p>Audible Response: Trigger the system sound and siren.</p> <p>Voice Prompt: Zone X panic alarm.</p>
Fire Zone	<p>The zone activates all the time with sound/siren output when alarm occurs.</p> <p>Audible Response: Trigger the system sound and siren.</p> <p>Voice Prompt: Zone X fire alarm.</p>

Hybrid Security Control Panel User Manual

Input Types	Operations
Gas Zone	<p>The zone activates all the time with sound/siren output when alarm occurs.</p> <p>Audible Response: Trigger the system sound and siren.</p> <p>Voice Prompt: Zone X gas alarm.</p>
Medical Zone	<p>The zone activates all the time with beep confirmation when alarm occurs.</p> <p>Audible Response: Trigger the system sound and siren.</p> <p>Voice Prompt: Zone X medical alarm.</p>
Timeout Zone	<p>The zone activates all the time. The zone type is used to monitor and report the "ACTIVE" status of a zone, but it will only report and alarm this status after the programmed time has expired (1 to 599) seconds.</p>
Disabled Zone	<p>Alarms will not be activated when the zone is triggered or tampered.</p> <p>Audible Response: No system sound (voice prompt or siren).</p>
Virtual Zone (Keypad/Keyfob)	<p>The system will immediately alarm when it detects triggering event after system armed.</p> <p>Audible Response: Trigger the system sound and siren.</p> <p>Voice Prompt: Buzzer beeps.</p>
Tamper Alarm	<p>The system will immediately alarm when it detects triggering event after system armed.</p> <p>Audible Response: Trigger the system sound and siren.</p> <p>Voice Prompt: Zone X tampered.</p>
Link	<p>Trigger the linked device when event occurs.</p> <p>e.g. The output expander linked relays will be enabled when the control panel is armed.</p>
Arm	<p>When armed: Voice prompt for fault. You can handle the fault according to the voice prompt.</p> <ul style="list-style-type: none"> • System sound for arming with card or keyfob. • Voice prompt for fault. You can handle the fault according to the voice prompt. • Fault event displays on client. You can handle the fault via client software or mobile client. <p>Voice Prompt: Armed/Arming failed.</p>

Appendix C. Output Types

Table C-1 Output Types

Output Types	Active	Restore
Arming	Arm the control panel	After the configured output delay
Disarming	Disarm the control panel	After the configured output delay
Alarm	When alarm event occurs. The alarm output will be activated after the configured exit/enter delay.	After the configured output delay, disarm the control panel or clear alarm
Zone Linkage	When alarm event occurs, the linked relay will output alarm signal.	After the configured output duration
Manual Operation	Enable relays manually	Over the triggering time or disable the relays manually

Appendix D. Event Types

Table D-1 Event Types

Event Types	Custom	Default 1 (client software notification)	Default 2 (alarm receiving center 1/2)	Default 3 (mobile client)	Default 4 (telephone)
Alarm and Tamper	x/v	v	v	v	v
Life Safety Event	x/v	v	v	v	v
System Status	x/v	v	x	x	x
Panel Management	x/v	v	x	x	x

Appendix E. Access Levels

Level	Description
1	Access by any person; for example the general public.
2	User access by an operator; for example customers (systems users).
3	User access by an engineer; for example an alarm company professional.
4	User access by the manufacturer of the equipment.

Table E-1 Permission of the Access Level

Function	Permission			
	1	2	3 ^a	4 ^b
Arming	No	Yes	Yes	No
Disarming	No	Yes	Yes	No
Restoring/Clearing Alarm	No	Yes	Yes	No
Entering Walk Test Mode	No	Yes	Yes	No
Bypass(zone)/Disabling/Force Arming	No	Yes	Yes	No
Adding/Changing Verification Code	No	Yes ^d	Yes ^d	Yes ^d
Adding/Editing Level 2 User and Verification Code	No	Yes	Yes	No
Adding/Editing Configuration Data	No	No	Yes	No
Replacing software and firmware	No	No	No	Yes

 **Note**

^a By the condition of being accredited by user in level 2. ^bBy the condition of being accredited by user in level 2 and level 3. ^dUsers can only edit their own user code.

- The user level 2 can assign the login permission of the controller to the user level 3 or level 4 in the settings page.
- The user level 2 should assign permissions to the user level 3 if the user level 3 wants to login the controller remotely.
- When the controller is bypassed, the user level 3 can login the controller without the permission assignment of the user level 2.

- When the controller is bypassed, the user level 3 can login the controller without the permission assignment of the user level 2.
- The user level 4 can login the controller only when the user level 2 or level 3 has assigned permissions to the user level 4.

Appendix F. SIA and CID Code

Table F-1 SIA and CID Code

SIA Code	CID Code	Description
BA	E130	Burglary Alarm
BH	R130	Burglary Alarm Restored
HA	E122	Silent Panic Alarm
HH	R122	Silent Panic Alarm Restored
NA	E780	Timeout Alarm
BH	R780	Timeout Alarm Restored
PA	E120	Panic Alarm
PH	R120	Panic Alarm Restored
BA	E131	Perimeter Alarm
BH	R131	Perimeter Alarm Restored
BA	E134	Entry/Exit Alarm
BH	R134	Entry/Exit Alarm Restored
TA	E137	Device Tampered
TR	R137	Device Tamper Restored
TA	E383	Detector Tampered
TR	R383	Detector Tamper Restored
TA	E321	Wireless Siren Tampered
TR	R321	Wireless Siren Tamper Restored
TA	E334	Wireless Repeater Tampered
TR	R334	Wireless Repeater Tamper Restored
ES	E341	Expander or Wireless Device Tampered
EJ	R341	Expander or Wireless Device Tamper Restored

Hybrid Security Control Panel User Manual

SIA Code	CID Code	Description
PA	E120	Keypad/Keyfob Panic Alarm
MA	E100	Medical Alarm
MH	R100	Medical Alarm Restored
GA	E151	Gas Leakage Alarm
GH	R151	Gas Leakage Alarm Restored
FA	E110	Fire Alarm
FH	R110	Fire Alarm Restored
OP	E401	Disarming
CL	R401	Away Arming
OA	E403	Auto Disarming
CA	R403	Auto Arming
BC	E406	Alarm Clearing
CL	R441	Stay Arming
CD	E455	Auto Arming Failed
BB	E570	Zone Bypassed
BU	R570	Zone Bypass Restored
CT	E452	Late to Disarm
AT	E301	AC Power Loss
AR	R301	AC Power Restored
YT	E302	Low System Battery
YR	R302	Low System Battery Restored
XT	E384	Low Keyfob Battery
XR	R384	Low Keyfob Battery Restored
YM	E311	Battery Fault
YR	R311	Battery Fault Restored
DK	E501	Keypad Locked
DO	R501	Keypad Unlocked
TS	E607	Test Mode Entered
TE	R607	Test Mode Exited

Hybrid Security Control Panel User Manual

SIA Code	CID Code	Description
RN	E305	Control Panel Reset
UY	E321	Wireless Siren Disconnected
UJ	R321	Wireless Siren Connected
UY	E381	Wireless Detector Disconnected
UJ	R381	Wireless Detector Connected
XT	E384	Wireless Detector Low Voltage
XR	R384	Normal Wireless Detector Voltage
ET	E333	Expander or Wireless Device Disconnected
ER	R333	Expander or Wireless Device Connected
UY	E334	Wireless Repeater Disconnected
UJ	R334	Wireless Repeater Connected
NT	E352	Cellular Data Network Disconnected
NR	R352	Cellular Data Network Connected
NT	E352	SIM Card Exception
NR	R352	SIM Card Restored
NT	E352	Network Flow Exceeded
NT	E351	IP Address Conflicted
NR	R351	Normal IP address
NT	E351	Wired Network Exception
NR	R351	Normal Wired Network
NT	E351	Wi-Fi Communication Fault
NR	R351	Wi-Fi Connected
XQ	E344	RF Signal Exception
XH	R344	Normal RF Signal

Hybrid Security Control Panel User Manual

SIA Code	CID Code	Description
/	E306	Expander Deleted
/	R306	Expander Added
/	E306	Detector Deleted
/	R306	Detector Added
/	E306	Wireless Repeater Deleted
/	R306	Wireless Repeater Added
/	E306	Wireless Siren Deleted
/	R306	Wireless Siren Added
BA	E130	Burglary Alarm
BH	R130	Burglary Alarm Restored
XT	E338	Low Wireless Device Battery
XR	R338	Low Wireless Device Battery Restored
YC	E354	Uploading Report Failed
YK	R354	Report Uploading Restored
LB	E627	Programming Mode Entered
LX	E628	Programming Mode Exited
CI	E454	Arming Failed
/	R250	Patrol
/	E306	Wireless Device Deleted
/	R306	Wireless Device Added
XT	E384	Low Wireless Siren Battery
XR	R384	Low Wireless Siren Battery Restored
NT	E351	Wired Network/Wi-Fi ATP Failed
NR	R351	Wired Network/Wi-Fi ATP Restored
NT	E352	Cellular Network ATP Failed
NR	R352	Cellular Network ATP Restored



See Far, Go Further